

FROMENTAL CHINOISERIE



CREATING YOUR CHINOISERIE ROOM

We aim to make the process of creating your own Chinoiserie Room a simple and enjoyable experience.
Our team will guide you through each step of the journey.

Design Layout

We have several standard layouts within our Chinoiserie Collection. Varying in both style and density, each of these layouts can be further tailored to suit your space.



Select Design Layout



Supply Drawings & Measurements
to our Team



Miniature Design Layout for Approval



Colourway

Hand-painted and hand-embroidered onto a variety of silk grounds, we have a wide range of standard colourways. Alternatively, you can create your own colourway using our custom service.



Select Standard Colourway



Custom Colourway Service
Select Background
& Supply Colour Brief



Add Embroidery
if required



Sample for Approval



Order Confirmed and Painting Begins

For more detailed information on how to order please speak to a member of our team.



Fromental wallcoverings are hand-made to order, tailored for each room. From supplied elevations and floor plan, we will place the design and panel seaming to ensure optimal installation.

Technical information

In order for the design to be tailored to your room, our technical team will draw elevations and formulate a panel plan (see measuring process). Our design team will then create a black and white miniature within these elevations. We will tailor the design to fit the space, taking care to avoid placing birds and butterflies within wall corners or on panel seams.

Measuring Process

A set of 2D technical drawings (including elevations and floorplan) are preferable. Alternatively we will require the following information:

- Accurate and detailed dimensions of the area specified for wallcovering.
- All openings including doors, windows and any reveals if applicable.
- Individual wall sizes – it is important that the wall corners are specified.
- Measurements and location of any key items of furniture (this will allow us to tailor the layout further and ensure no key design features are obscured)

Tolerance

Standard tolerance on panel height is around 300mm/12", this will be split between the top and bottom of the panel. All tolerance values will be shown on the miniature.

